



## Antique Brass Elite FLAT & STEPPED

Tel: +971 4509 6719  
E: heritagebrass@live.com  
www.heritagebrass-uae.com



Box Depth



Box Depth

### 10 AMP Rocker Switches

	CODE	AED	CODE	AED	
1 Gang 2 Way Switch	T91.800.ABBK	76	S91.800.ABBK	76	25
2 Gang 2 Way Switch	T91.810.ABBK	88	S91.810.ABBK	88	25
3 gang 2 Way Switch	T91.820.ABBK	114	S91.820.ABBK	114	25
4 gang 2 Way Switch	T91.830.ABBK	154	S91.830.ABBK	154	25
1 Gang Intermediate	T91.801.ABBK	102	S91.801.ABBK	102	25

### 13 AMP Switched Sockets

Single 13 AMP socket	T91.840.ABBK	88	S91.840.ABBK	88	35
Double 13 AMP socket	T91.850.ABBK	110	S91.850.ABBK	110	35

### 13 AMP Fused Spur Units (Connection Units)

Unswitched Spur	T91.834.BK	106	S91.834.BK	106	35
Switched Spur	T91.835.ABBK	116	S91.835.ABBK	116	35
Switched with neon	T91.836.ABBK	132	S91.836.ABBK	132	35
Switched with neon/cord	T91.838.ABBK	167	S91.838.ABBK	167	35

### 20 AMP Dolly Switches

1 gang dolly	T91.3400.AB	160	S91.3400.AB	160	35
2 gang dolly	T91.3410.AB	210	S91.3410.AB	210	35
3 gang dolly	T91.3420.AB	294	S91.3420.AB	294	35
4 gang dolly	T91.3430.AB	350	S91.3430.AB	350	35
1 gang Intermediate	T91.3401.AB	185	S91.3401.AB	185	35

### 2 Way Push On/Off Dimmer Switches

1 gang dimmer (400 watts)	T91.971/400	150	S91.971/400	150	35
2 gang dimmer (400 watts)	T91.972/400	200	S91.972/400	200	35
3 gang dimmer (400 watts)	T91.973/400	250	S91.973/400	250	35
4 gang dimmer (400 watts)	T91.974/400	300	S91.974/400	300	35

### Low Voltage Dimmer Switches

1 gang Low Voltage 400VA	LV T91.971/400	170	LV S91.971/400	170	35
2 gang Low Voltage 400VA	LV T91.972/400	220	LV S91.972/400	220	35
3 gang Low Voltage 400VA	LV T91.973/400	270	LV S91.973/400	270	35
4 gang Low Voltage 400VA	LV T91.974/400	330	LV S91.974/400	330	35

### 20 AMP D.P. Switches

20 AMP D.P. Switch	T91.805.ABBK	100	S91.805.ABBK	100	35
20 AMP Switch with Neon	T91.806.ABBK	114	S91.806.ABBK	114	35

### 45 AMP Cooker Switches

45 AMP Neon (twin) Red Rocker	T91.961.BK	210	S91.961.BK	210	48
45 AMP (single) Red Rocker	T91.963.BK	180	S91.963.BK	180	48
45 AMP cooker unit & 13A socket	T91.962.BK	260	S91.962.BK	260	48

### Flex Outlet

1 Gang flex outlet	T91.909.BK	108	S91.909.BK	108	25
--------------------	------------	-----	------------	-----	----

### Round Pin Sockets Unswitched

5 AMP 3 pin	T91.982.BK	130	S91.982.BK	130	35
-------------	------------	-----	------------	-----	----

### Shaver Socket Dual Output

Output voltage 110/240V	T91.985.BK	260	S91.985.BK	260	48
-------------------------	------------	-----	------------	-----	----

### TV/Coaxial Sockets

Single Non-Isolated	T91.921.BK	100	S91.921.BK	100	35
Single Isolated	T91.923.BK	122	S91.923.BK	122	35
Twin Non-Isolated	T91.922.BK	122	S91.922.BK	122	35
TV/FM Diplexed	T91.924.BK-DIP	150	S91.924.BK-DIP	150	35

### Satellite Sockets

Satellite Socket	T91.925.BK	122	S91.925.BK	122	35
TV/Satellite Socket	T91.926.BK	140	S91.926.BK	140	35
TV/FM/Satellite Triplex	T91.616.BK	160	S91.616.BK	160	35

### Telephone and Data Sockets

1 Gang Secondary Line	T91.966.BK	110	S91.966.BK	110	35
1 Gang Master Line	T91.967.BK	118	S91.967.BK	118	35
2 Gang Secondary line	T91.956.BK	140	S91.956.BK	140	35
2 Gang Master line	T91.957.BK	150	S91.957.BK	150	35
1 Gang RJ45 CAT6	T91.968.BK	130	S91.968.BK	130	35
2 Gang RJ45 CAT6	T91.958.BK	140	S91.958.BK	140	35

### Blanking Plates

Single Section Blank	T91.931	66	S91.931	66	~
Double Section Blank	T91.932	88	S91.932	88	~